

OPERATING INSTRUCTIONS & SAFETY INSTRUCTIONS

Playhouse for children - Model No.: 081 Cream/White



Read the operating instructions carefully, especially the warnings, before assembling the playhouse. Failure to do so may result in injury or damage to the playhouse. Keep these instructions for future use. If you pass the house on to someone else, please pass these instructions on as well.

Intended use:

The playhouse is designed exclusively for children to play with and is intended for private use and is not suitable for commercial use.

Safety instructions:


- ATTENTION! Not suitable for children under 3 years.
- CAUTION! Long cord. Danger of strangulation.
- Do not hang decorations, fairy lights or other items in or on the playhouse that children could get caught on while playing.
- Make sure there is always an escape route from the house.
- Improper assembly and use can lead to injury. Set up the house on a level surface. Keep a distance of 1.5 m in all directions from other structures.
- Only allow children to use the house under supervision.
- The playhouse must be assembled by an adult.
- Keep the house away from extreme temperatures and open flames.

Storage:




- Keep the playhouse out of the reach of children.






Cleaning and care:




- We recommend washing the house only by hand and ironing it before assembly.



SCOPE OF DELIVERY:

The rod	Number	Size	Form
 A	24	41,6 cm x 1,9 cm	round
 B	8	28,6 cm x 1,9 cm	round
 C	3	41,6 cm x 2 cm	flat





connectors	 E	 F	 G	 H	 I
Number	2 (flat)	4	4 (round)	2	18
size/angle	90°	135°	90°	6 x 2,4 cm	8 x 2,4 cm

1 x Fabric J 	1x Mat K 	1 x Pennant Chain L 
--	---	--

ASSEMBLY INSTRUCTIONS:

1

Use the rods and connectors as described to obtain the following rods:


I	3 x C rods + 2 x H connectors 	1 piece	125,4 cm
II	3 x A rods + 2 x I connectors 	4 pieces	125 cm
III	2 x A rods + 1 x I connector 	6 pieces	83,3 cm
IV	2 x B rods + 1 x I connector 	4 pieces	57,5 cm



Please press the components together firmly!


2

You will need: 1x pole I, 1x pole II, 2x poles III, 2x connectors G and 2x connectors E. Put the floor of the playhouse together as shown. The flat pole is for the door side of the playhouse to make it easy to crawl in and out.



3

Now use 4x rod III and 4 connectors F to assemble the vertical side walls of the playhouse.




You can also find detailed video assembly instructions on YouTube.

The user manual in other languages can be found on our website www.lionherz.at



4

To assemble the roof you will need 3x rod II, 4x rod IV and 2x connecting piece G. Put everything together as shown and make sure that all parts are firmly connected.



5

Finally, place the tent fabric J over the pole construction and close the zipper at the bottom of the playhouse.

ATTENTION: The flat pole on the front of the house can be pushed into an extra fabric tunnel.

Then place the floor mat K in the playhouse and attach the pennant chain L to the 2 tabs provided on the roof of the house.



COMPLETE :)

THANK YOU VERY MUCH FOR YOUR TRUST AND WE WISH YOU A LOT OF FUN PLAYING

your Martina from
LIONHERZ